


THE RED TRACES ON THE TOP LAYER ARE STRAPS THERE ARE 8



FOR PNP USE PRINT BOTTOM FOIL ON TO PNP BLUE SHEET IRON ON AND ETCH AS PER NORMAL
 AFTER DRILLING THE BOARD I DO THE FOLLOWING
 PRINT THE TOP OUT ON STANDARD PAPER USING A BUBBLEJET PRINTER
 CUT IT OUT TO THE SIZE OF THE BOARD AND ATTACH USING SERVISOL BOARD LACQUER
 SPRAY THE BOARD THEN LAY THE PAPER OVER TRY TO LINE IT UP AS BEST YOU CAN
 THEN RESPRAY SOME MORE OVER THE TOP
 ALLOW TO DRY FOR ABOUT AN HOUR AND THEN USING A PIN PIERCE THE PAPER FOR ALL HOLES
 NOW YOU HAVE A EASY, CHEAP AND NASTY SILKSCREEN LEGEND TO FOLLOW