

TUNE
VCO 1 FREQUENCY
VCO 2 FREQUENCY
VCO 3 FREQUENCY
PORTAMENTO
LINEAR DETUNE
PULSE WIDTH
VIBRATO RATE
FM
PWM DEPTH
VIBRATO DEPTH
1V/OCT
VIB DEPTH
FM
PWM
DRIVER OUT
VCO LINK
SAW
PULSE
VCO DRIVER
VCO 1
VCO 2
VCO 3
JÜRGEN HAIBLE
LIVING VCOs