



NOTES:

POWER CONDITIONING:

This module runs on +/- 12 volts. It can use +/-15 if you add the regulators. If regulators are not needed/used, do not install the associated components such as C13, R62, R65, R66, and D10 for the LM317, and C10, R70, R72, R73, and D12 for the LM337.

Solder a jumper between the IN and OUT pins respectively in place of the unused regulator, pins 2 and 3 in each case.

The LEDs and respective current limiting resistor only need to be installed if the circuit load is insufficient for the respective regulator. See the LM317 and LM337 data sheet for minimum load specifications.

MISC:

* Install either the trimmer or the panel control. Not both

SP_Microcon_1.0	
TITLE: Microcon	
Document Number:	REV:
Date: 9/20/2011 10:46:49 PM	Sheet: 1/1

Copyright 1976, 2010 Nyle Steiner and Analogue Realities. All rights reserved