

GS Drum Presets - 3

#	Note	128: CM-64/32L	#	Note	128: CM-64/32L
35	B0	Acoustic Bass Drum	83	B4	Door Creaking
36	C1	Acoustic Bass Drum	84	C5	Door Closing
37	C#1	Rim Shot	85	C#5	Scratch
38	D1	Acoustic Snare Drum	86	D5	Wind Chimes
39	D#1	Hand Clap	87	D#5	Car Engine
40	E1	Electronic Snare Drum	88	E5	Car Brakes
41	F1	Acoustic Low Tom	89	F5	Car Passing
42	F#1	Closed Hi-Hat	90	F#5	Car Crash
43	G1	Acoustic Low Tom	91	G5	Siren
44	G#1	Open Hi-Hat 1	92	G#5	Train
45	A1	Acoustic Mid Tom	93	A5	Jet Plane
46	A#1	Open Hi-Hat 2	94	A#5	Helicopter
47	B1	Acoustic Mid Tom	95	B5	Starship
48	C2	Acoustic Hi Tom	96	C6	Gun Shot
49	C#2	Crash Cymbal	97	C#6	Machine Gun
50	D2	Acoustic Hi Tom	98	D6	Laser Gun
51	D#2	Ride Cymbal	99	D#6	Explosion
52	E2		100	E6	Dog Bark
53	F2		101	F6	Horse Gallop
54	F#2	Tambourine	102	F#6	Birds Tweet
55	G2		103	G6	Rain
56	G#2	Cowbell	104	G#6	Thunder
57	A2		105	A6	Wind
58	A#2		106	A#6	Seashore
59	B2		107	B6	Stream
60	C3	High Bongo	108	C7	Bubble
61	C#3	Low Bongo			
62	D3	Mute Hi Conga			
63	D#3	High Conga			
64	E3	Low Conga			
65	F3	High Timbale			
66	F#3	Low Timbale			
67	G3	High Agogo			
68	G#3	Low Agogo			
69	A3	Cabasa			
70	A#3	Maracas			
71	B3	Short Whistle			
72	C4	Long Whistle			
73	C#4	Quijada			
74	D4				
75	D#4	Claves			
76	E4	Laughing			
77	F4	Screaming			
78	F#4	Punch			
79	G4	Heartbeat			
80	G#4	Footsteps 1			
81	A4	Footsteps 2			
82	A#4	Applause			