


Top View of Daughterboard



No connection on pins 2, 8, 12, 13, 16

Most cards have pins 6, 10 and 14 connected together and pins 1,3,5,7,9,11 connected together  
And pins 15, 17, 19, 21, 23 and 25 connected together, so you can generally connect to just one of those pins for each group.